

ELITE RC-1 AATD Start Instructions

POWER-UP

1. Turn the large TV screen ON with the remote control. Make sure to point the remote control to the left-hand bottom corner of the TV where the receiver is located.
 - a. If needed, select HDMI 1 as input source.
 - b. If there's no signal, press the Power button on the VISUAL computer to start it up.
 - c. If you see Windows desktop, but no rotating ELITE logo, you can start it manually by clicking on the Elite icon, on the Task Bar or on the Desktop shortcut.
2. If the MAIN computer Instructor screen is dark, move mouse or press a key on a keyboard to wake it up. If it wakes up, proceed to log-on instructions
3. Press the Power button on the MAIN computer. The sequence doesn't matter, but the VISUAL computer takes more time to boot, so it's better to start it first.

LOG-ON

1. The VISUAL computer doesn't require logging in. The log in is automatic. The ELITE VISUAL screen with rotating ELITE logo should appear in a couple of minutes after Windows start-up. If it doesn't happen, you can start it manually by clicking on the Elite icon, on the Task Bar or on the Desktop shortcut.
2. When presented with log-in screen on the MAIN computer Instructor station,
 - a. If the user Instructor is listed in the user list on the left-hand lower corner of the screen, click on it.
 - b. Otherwise click on Other User and type .\Instructor in the Email box
 - c. Click on the arrow next to the Password field. The password is blank for the user Instructor.

STARTING ELITE SOFTWARE

1. Make sure the VISUAL computer is fully booted and you see the rotating ELITE logo. If there's any malfunction on the VISUAL computer and you are unable to start the visual software, you can still use the simulator but without visual portion.
2. Note the starting Hobbs time in the timesheet log.
3. Turn-on the key on the Elite Pro Panel
4. Start the ELITE RC-1 AATD by clicking on the shortcut on the desktop or on the Taskbar
5. Select Region
6. Select Airplane
7. If there's a message about the Throttle or other controls not identified, move the levers out of extreme limits.
8. If there's a message about visual configuration required for various currency tasks, click OK and proceed.

SHUT-DOWN

1. Turn the key on the ELITE ProPanel to the OFF position
2. Note the Hobbs time in the timesheet log. Take a picture of it and email or text it to Julian.
3. Close ELITE software by pressing ALT-Q or by selecting QUIT on the menu.
4. There's no need to shut-down Windows or log-off. Both computers will go to power saving sleep mode after a couple of hours if no activity is detected.